



Product How-To's

Drilling Holes in Rowmark Material

When drilling holes in Rowmark material for mounting, framing, etc., it is recommended that you use a drill bit specifically designed for use with plastics and acrylics. Traditional wood-working drill bits usually create holes with a greater chance of breakout on the reverse (bottom) side of the sheet. The heat generated by wood-working drill bits can also cause burrs and melting of the plastic.

Abbeon Cal, Inc. offers Plexi-Point drill bits designed specifically for plastics and acrylics. You can find those drill bits on their website at this address: <http://www.abbeon.com>.

*** Note – Rowmark is not affiliated with and does not receive any compensation from Abbeon Cal, Inc., and provides this recommendation only as a courtesy to our customers.**