Rowmark



Textures

Serving Tray

INSTRUCTIONS

We used 1/8" Royal Blue/White Rowmark Textures material, but you could pick any color that suits your fancy!

- 1. Import your design and adjust power and speed settings.
- 2. Place your blue sheet into your laser bed. Use the focus tool to adjust to the top of the material. Focusing should be done each time a new material is introduced.
- 3. Run the cut file job
- 4. Remove the masking from your material and import your engrave file.
- 5. Run engrave file.
- 6. Using a strip heat bender you can bend the edges of your serving tray.

FILES INCLUDED





